

FIRE ORIGIN, LEVEL - LV

Fire Origin - Level refers to the floor or area where the fire originated. If there are no intervening floors or irregularly spaced floors, it refers to the height above grade where the fire originated.

- 1000 Basement, sub-basement
- 1100 Mezzanine (any floor)
- 2000 Crawl space, under structure
- 3000 Ground floor, grade level or grade to 3m (10ft)
- 4000 2nd storey or over 3m to 6m (10ft to 20ft) above grade
- 5000 3rd storey or over 6m to 9m (20ft to 30ft) above grade
- 6000 4th to 12th storey (inclusive) or over 9m to 36m (30ft to 120ft) above grade
- 7000 Over 12 storey or over 36m (120ft)
- 8000 Roof level (includes concealed roof space, attic)
- 9000 Exposure fire

- 0000 Cannot be determined
- 0008 Not applicable (e.g. vehicle, outdoor person)